




MCP OPERATIONS **Display Screens** The display shows information depending on the current function or status of the MCP. The following are the most common screens shown in the MCP: Display shows: Shows when: FIRE ALARM The fire alarm is activated (heat detector NO DC POWER!! and/or smoke detector is activated). C SYSTEM OFF There is an internal error of **NETWORK NOT RESPONDING!!** communication. SYSTEM FAULT! CALL FOR SERVICE! SYSTEM DIV2006V1.00 The system is starting. CPU= 0.00 CAN=00.00 В В TOP ADDRESS = 0 Please wait... Recycling system The Sort Mode is selected, in this state, **SORT MODE** the system is ready to operate. Ready Α WILKINSON-HI-RISE 3001 Greene Street Hollywood, FL 33020 This Drawing is the property of WILKINSON HI-RISE. It is loaned on the condition that Ph. 954 342 4400 it is not to be reproduced, copied or otherwise disposed if, and is not to be used in part to furnish information for the making of drawings, prints, or parts there of. The acceptance of the foregoing conditions and the recognition of the exclusive ownership in and to the drawings as the property of WILKINSON HI-RISE. SHEET #3 BY JCR DATE 9/27/2012 5 6 8 3





:	D
09	
o the	
	C
	В
ON-HI-RISE	A
R DATE 9/27/2012 8	1
	ON-HI-RISE

	1	2	3	4	5	6	7	8				
		3 = FLOOR ON/OFF										
D		1	SET ALL FLOORS OFF			D						
		2	SET ALL FLOORS ON	ALL F	ALL FLOORS 1 - TOP ADDRESS # WILL BE SET = 1 (ON)							
		3	FLOOR # = ADDRESS #	FLOOR # USE	FLOOR # USED IN DISPLAY REFERENCES WILL BE SET TO ADDRESS #							
		4	MANUAL ENTRY	F1-EXIT, F2-MOVE TO	-EXIT, F2-MOVE TO PREVIOUS GROUP, F3-MOVE TO NEXT GROUP (SEE NOTE #1)							
		F1 RETURN TO PREVIOUS MENU										
C		4 = D-Tir	NE A TIME THE SYSTEM IDLI	ES AFTER INTAKE DO	OOR IS CLOSED. Aft	er this time flaps move	e to default position		С			
		1	GARBAGE	(garbage) and IN US			·					
			1	DEFAULT		L LOAD DEFAULT TABLI						
			2	MANUAL		(MODIFY) DROP TIME TA DS. VALUES ARE IN SEC						
		2	NEWSPAPER									
			1	DEFAULT		L LOAD DEFAULT TABLI ESS NUMBER'S BY INCR						
В			2	MANUAL		(MODIFY) DROP TIME TA DS. VALUES ARE IN SEC			В			
		NOTE:	FLOOR NUMBER MAY NOT THEN WE CAN ASSIGN ADDI									
A	This Drawing is the n	WILKINSON-H 3001 Greene Street Hollywood, FL 33020 Ph. 954 342 4400										
	it is not to be reprodu furnish information fo of the foregoing cond	uced, copied or otherwise or the making of drawing	e disposed if, and is not to be used in p s, prints, or parts there of. The accepta n of the exclusive ownership in and to	part to		SHEET #7		ATE 9/27/2012				
	1	2	3	4	5	6	7	8				



	1	2	3	4	5	6	7	8			
D	TROUBLESHOOTING This section can help you solve some problems associated with errors shown in the display										
		Display s	hows:		Problem:		To solve:				
		NETWORK NOT SYSTEM CALL FOR	FAULT!	11	is an internal er unication.	conn supp	Check if the MCB is connected to power supply.				
С	[DIVER	TER	The cl	ean-out door loo	off, th	Turn the PLC switch to off, then reset MCP. Close the door located				
		CLEAN-OUT D SYSTEM CLOSE	IS "OFF"		sorter/bisorter is tly open.	s on Bi	sorter.				
В		COMPA POWER OF SYSTEM REPLACE C	F or FULL IS "OFF"	Power	ompactor is full o Pack is off.	is turi Chec	k if the power paned on. k if the compactor, and empty the liner.				
		DIVER FAU CHECK GARE F1 - F	ILT! BAGE INSIDE	trisort	is an error in the er/bisorter and n checked.		ck if there's trash disorter and remo				
A	it is not to be r furnish informa	is Drawing is the property of WILKINSON HI-RISE. It is loaned on the condition that is not to be reproduced, copied or otherwise disposed if, and is not to be used in part to mish information for the making of drawings, prints, or parts there of. The acceptance the foregoing conditions and the recognition of the exclusive ownership in and to the									
		g conditions and the recognition of the property of WILKINSON HI-RISE.	e exclusive ownership in and to	4	5	SHEET #9	BY JCR DA	ATE 9/27/2012 8			

	1	2	3		4	5		6	7	8	
D		COMPA FAU SYSTEM CHECK CO		There is an error in the compactor / power pack an needs to be checked			Check if the power pack has energy. Verify if there is oil leakage or another error in the power pack or compactor				
		POWE SYSTEM	ACTOR R OFF IS "OFF" MPACTOR!		The po	wer pack does nergy.	n't	·	on the power pack.		
С		POWER OF SYSTEM	ACTOR FF or FULL IS "OFF" CONTAINER		-	ower pack does nergy or is full	n't	Check trash	on the power pace on the compact on the compact on the compact	ne	С
В		Motor OV	r hydraulic 'ERLOAD ERVICE		the cor	is an overload i npactor and the re has been ded		check obstru compa	the system off a if nothing is ucting the actor. or service.	and	В
		MISSING FLO 0 0 0 0 F1 - EXIT F2 -	0 0 0 0			ors' addresses rectly configure		addre On/of	erly configure th ess in the Floor f section of the setup page	e	
A	it is not to be re furnish informa of the foregoing	the property of WILKINSON HI-RIS eproduced, copied or otherwise dis- tition for the making of drawings, pri g conditions and the recognition of p property of WILKINSON HI-RISE.	posed if, and is not to be used in ints, or parts there of. The accept	part to ance the	4	5		300 Ho	WILKINSON- D1 Greene Street Ilywood, FL 33020 954 342 4400 D BY JCR D2 7	HI-RISE ATE 9/27/2012 8	A